


# INSTALLATION INSTRUCTIONS

## SCONCE

### CIRO SCONCE

ART. NO. 100 116bz	bronze, yellow and red glass	100 119mc	matte chrome, white fritted glass
100 116ch	chrome, yellow and red glass	100 121bz	bronze, gold-leaf glass
100 116mc	matte chrome, yellow and red glass	100 121ch	chrome, gold-leaf glass
100 117bz	bronze, yellow and blue glass	100 121mc	matte chrome, gold-leaf glass
100 117ch	chrome, yellow and blue glass	100 122bz	bronze, red glass
100 117mc	matte chrome, yellow and blue glass	100 122ch	chrome, red glass
100 118bz	bronze, mosaic glass	100 122mc	matte chrome, red glass
100 118ch	chrome, mosaic glass	100 123bz	bronze, lava glass
100 118mc	matte chrome, mosaic glass	100 123ch	chrome, lava glass
100 119bz	bronze, white fritted glass	100 123mc	matte chrome, lava glass
100 119ch	chrome, white fritted glass		



## IMPORTANT SAFETY INSTRUCTIONS



1. Read all instructions!
2. Turn off power prior to any work on the canopy.
3. THIS PRODUCT MUST BE INSTALLED BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED, IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODE.
4. This wall sconce MUST BE HARD WIRED, 120v. For all the wire connections, use Listed Wire Nuts.
5. Only BRUCK Uni-Light fixtures may be used with the wall sconce.
6. Total wattage of the fixture must never exceed the wattage supplied by the low voltage electronic transformer. Please check that the total lamp wattage does not exceed 50W.
7. Secondary connections must be clean and tight to avoid arcing and overheating!
8. Warranty is void in case of unauthorized modifications and/ or improper use.

READ ALL OF THESE INSTALLATION INSTRUCTIONS BEFORE INSTALLING THE SYSTEM

This Package Contains:  
 CIRO SCONCE w/ transformer - qty.(1)

The Ciro Sconce can be mounted directly to any wall with access to the power cables. Begin by connecting the two wires from the transformer (A) to the power cables in the wall. Then slide the notched plastic washer (B) through the mounting screw (C). Insert the screw (C) into the mounting plate (D) and slide the plastic washer (E) onto the end of the screw. Align the screws (C) with the J-box and tighten until firmly connected.

Place the canopy cover (F) over the mounting plate (D) and secure it with the allen screw (G) located on the side of the base.

Insert a Bi-Pin lamp into Ciro socket, by unscrewing Ciro Glass (H).

