


# INSTALLATION AND WIRING DIAGRAM

USA

## LEDRA SERIES LEDS

### LEDRA™ FLEX 4"

ART. NO.	135 763/s	white, 10° lens	135 763-1/s	warm white, 10° lens
	135 763/m	white, 30° lens	135 763-1/m	warm white, 30° lens
	135 763/fl	white, 45° lens	135 763-1/s	warm white, 45° lens



## IMPORTANT SAFETY INSTRUCTIONS



1. THIS PRODUCT MUST BE INSTALLED BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED, IN ACCORDANCE WITH THE LOCAL NEC CODE.
2. Save these instructions and refer to them when additions to or changes to the fixture are made.
3. Do not install this fixture in damp or wet locations.
4. CAUTION - Do not install any fixture assembly closer than 6 inches from any curtain, or similar combustible material.
5. Turn off power prior to any work on the system.
6. Warranty is void in case of unauthorized modifications and/ or improper use.

READ ALL OF THESE INSTALLATION INSTRUCTIONS BEFORE INSTALLING THE FIXTURE

### Contents of Delivery: Ledra Flex 4" - qty. (1)

- Begin by connecting the two wires (A) from the transformer to the power cables in the wall.

- Insert the mounting screw (C) into the mounting plate (B).

- Align the mounting screws (C) with the J-box and tighten until firmly connected.

- Place the Ledra Flex 4" (D) over the mounting plate (B) and secure with the allen screws (E) located on the side of the base.

