


INSTALLATION INSTRUCTIONS

USA

FLEX-LINE

FLEX-LINE CEILING SUSPENSION III

Art. No. 230101 matte chrome



IMPORTANT SAFETY INSTRUCTIONS



1. Read all instructions!
2. Turn off power prior to any work on the canopy.
3. THIS PRODUCT MUST BE INSTALLED BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED, IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODE.
4. Only Flex-Line components may be used with this Flex-Line support.
5. Mounting hardware supplied with supports may not be suitable for all installations.
6. Warranty is void in case of unauthorized modifications and/ or improper use.

READ ALL OF THESE INSTALLATION INSTRUCTIONS BEFORE INSTALLING THE SYSTEM

This Package Contains:
Flex-line Ceiling Suspension III - qty.(1)

Installation:

Begin by unscrewing the support rod (A) from the mounting base (B).

Use the provided screw* (C) to mount the base (B) to the desired ceiling surface. Connect the support rod back onto the base.

Unscrew the support cap (D) and insert Flex-Line track. The direction of the support head (E) can be adjusted by loosening the allen screws (F).

Field shortening:

The Ceiling Support III can be field cut with a hack-saw to desired lengths. Remove the support head (E) by loosening the allen screws (F). Cut the support rod (A) with a hack-saw (make sure you do not cut the threaded end). Replace the support head.

*provided mounting hardware may not be suitable for all installations.

